


5. SPARE PARTS OVERVIEW

A1 = LCD SLIDE ASSY




- 2X SCREWS M1.6x4.1 I035
- 4 x SCREWS M1.4x2.4 I019
- 2X SCREWS M1.6x7.5 I036

A4 = D-COVER ASSY



A3 = ANTENNA ASSY



A1= LCD SLIDE ASSY incl. A2
 A2= C-COVER ASSY
 A3= ANTENNA ASSY
 A4= D-COVER ASSY
 * = ONLY AVAILABLE AS ASSEMBLY